

XLR2UTP Installation

XLR2UTP connects your external wireless microphone receiver with XLR output such as Sennheiser, AKG, Audiotechnica, Shure, ... into Yealink MS Teams and Zoom Room devices.



Installation

XLR F audio input - to the output of your wireless mic receiver
RJ45 PoE input - to your existing Yealink PoE switch

Use only with VCM35 microphones (or with no other mics).
See our similar products for installations with other Yealink microphones.

The number of XLR2UTP units per Yealink video room device follows the same rules as for VCM35 mics.

Speech from wireless microphone is transmitted to the remote side, it is not played back locally.

You can rename your XLR2UTP (which is first recognized as VCM35) to e.g. "Wireless" and you can separate Mute control in the Yealink RoomConnect application.

Rename Mic

<https://support.yealink.com/en/portal/knowledge/show?id=6459d54c0a11b818a7542888>

Separate Mute control

<https://support.yealink.com/en/portal/knowledge/show?id=6459d54c0a11b818a7542888>